

# Community College Allegheny County



## Touch Panel User Manual

Audio Visual Systems installed by Dobil Laboratories

727 Butler Street  
Pittsburgh Pa. 15223  
(412)-782-3399  
[www.dobil.com](http://www.dobil.com)

## Table of contents

<b>Page/ Description</b>
--------------------------

- 1. Cover.**
- 2. Table of contents.**
- 3. Welcome**
- 4. Main Page**
- 5. PC Page**
- 6. Laptop Page**
- 7. Document Camera Page**
- 8. DVD Page**
- 9. VCR Page**
- 10. Shut Down Page**
- 11. Are You Sure**
- 12. Cooling**

# Welcome Page



## **FORWARD**

This is a User Manual for the Audio Visual system installed at the school.


From this Touch Panel a person can...

1. Turn On and Off the Sound and Video system.
2. Project and broadcast any of the sources installed in the lectern.
3. Control the selected sources that are being displayed.

The touch panel will black out the display after 10 minutes.  
To illuminate the backlight simply touch the panel.

- 1 Press START to turn on the projector and sound system.

# Main Page




1 When first turning on the system the projector will take 60 seconds to warm up. In order to protect the projector, the QUIT button will not work during this time.

2 These are the available sources in the system. Press any of the Hard buttons to display it's selected source.

The following pages will describe these selections and their control.

## PC Page



- 1** The PC with internet access is located in the Lectern.  
The PC is outfitted with a SMART Technologies monitor that is capable of annotation. Refer to the SMART user manual for more details.
- 2** Press the Pic Mute button to hide the projected image.  
Press it again to bring the image back.  
The Picture Muted LED will be illuminated while Pic Mute is on.
- 3** Volume control for the selected source can be controlled here.

# Laptop Page




- 1 Press this button to select the Laptop.  
There is a cable on the lectern for both Laptop audio and video.



- 2 Auto Image will center and align the image on the projector.

## Document Camera Page



1 Press this button to select the Document Camera.

2 Control for the Document Camera can be obtained here.

## DVD Page



1 Press this button to select the DVD player.

2 Control for the DVD player can be obtained here.



## VCR Page



1 Press this button to select the VCR.


2 Control for the VCR can be obtained here.

## Shut Down Page



- 1 Press the QUIT button at any time to start the shut down dialog.

## Are You Sure



- 1** Press YES to shut down the system.  
This includes the projector, and sound system.  
The system will cool for 2 minutes and then will be ready to use again.
- 2** Press NO to go back.

# Cooling



- 1 After the cooling bargraph is complete the system will be ready to use.

END